

FM/1 8 0 0 0 - MACHINES/ATTACHMENTS/PARTS

<u>CODE</u>	<u>DESCRIPTION</u>
6605	FM/18000 - 18" UTILITY FUSING MACHINE
6606	FM/18000VETW - WAISTBAND FUSING MACHINE
6629	FM/18000E - ECONOMY FUSING MACHINE
6649	FM/18000F - FURNITURE SKIRT FUSING MACHINE
6627	CRATING
6634	WAISTBAND ATTACHMENT
6636	WORK TABLE EXTENSION
6632	ATTACHMENT MOUNT
1848	TEFLON COVER - 18" (NON-EXTENDIBLE)
1849	EXTENDIBLE TEFLON COVER - 18"
1851	TOP BELT - 18"
1852	WHITE TOP BELT - 18"
7000	BROWN TEFLON
9003	BLACK TEFLON FOR WORK SURFACES
997	DRIVE ROLLER
1001	ROLLER
1004	GREASE ROLLER AXLE BEARING
1005-18	MOTOR
1006	MOTOR CHAIN GUARD
1007	DRIVE ROLLER SPROCKET
1008	MOTOR SPROCKET
1009	DRIVE CHAIN
1264	HIGH TEMPERATURE GREASE
1012	TOP ELEMENT SIZE:1½" x 12"SPECIFY VOLTAGE
1016	BOTTOM ELEMENT SIZE: 3" x 14" SPECIFY VOLTAGE
1020	ELEMENT MOUNT PLATE
1022	ELEMENT RETAINING BRACKET
1023	THERMOSTAT
1024	PILOT LIGHT
1025	ON/OFF SWITCH

<u>CODE</u>	<u>DESCRIPTION</u>
1026	ODH - ON/OFF DELAY
1028	THERMOSTAT KNOB
1029	MOTOR BRUSHES – MUST SUPPLY DESCRIPTION
1033	56VC SPEED CONTROL W/POTENTIOMETER
1034	WIRE, HIGH TEMPERATURE
1036	RR77 BELT CLEANER/RESIN REMOVER
1030	"U" SHAPED LIFTING ROD
1031	SLIDER PLATE FOR LIFTING ROD
1087	ELBOW TO FEMALE GREASE FITTING
1088	90° GREASE FITTING
1089	STRAIGHT GREASE FITTING
1090	HEAD LIFTING BAR
1091	HEAD LIFTING PRESSURE NUT
1092	"T" SHAPED LIFTING ASSEMBLY (OVER HEAD)
1093	BELT TENSION CONTROL KNOB
1094	ROLLER RETAINING RINGS
1095	LIFTING PIN HOLDING BLOCK
1096	LIFTING PIN
1297	LIFT ASSEMBLY MOUNTING PLATE
1299	MOTOR MOUNT PLATE
1802	SEPARATING RODS
1204	1205 BELT TENSION ASSEMBLY COMPLETE
1205	ADJUSTABLE ROLLER MOVING BLOCK
1206	ADJUSTABLE ROLLER BEARING SHIELD
1207	ADJUSTABLE ROLLER BEARING ROD
1210	SIDE PLATE
1212	SIDE PLATE END COVER
1226	TOP TRACKING GUIDE HOLDER
1227	TOP TRACKING GUIDE PIN
1236	TOP TRACKING GUIDE BEARING