

**SINGER**  
**503W1**

# PRICE LIST

OF

# PARTS



## MACHINE No. 503w1

---

### INDEX

---

	PAGE
ACCESSORIES .....	8
MACHINE No. 503w1 .....	7
NUMERICAL LIST OF PARTS .....	9

# Instructions for Ordering

In ordering from this list, use **ONLY** the **PART** number in the **FIRST** column.

The number stamped on a Sewing Machine Part is the number of the Single Part only, except when the part includes Feet Screws, Clamping Screws, Studs and Rollers Spun on, Small Wires riveted, or Parts soldered together, etc., which it is necessary to furnish in combination.

Every combination of parts sent out has its specific number which, although not stamped on Parts (except in above cases) must be used when ordering the combination.

Each number always indicates the **SAME PART** in whatever list it appears, or for whatever Machine.

The letters after some of the numbers indicate the style of finish only, as follows:

- A. Hardened, Polished and Plated.
- B. Polished and Plated.
- C. Hardened only.
- D. Polished only.
- E. Soft, not polished.
- F. Hardened and Polished.
- H. Blued.

These letters **MUST BE USED** when they appear in the list and **AFTER** the number, as in the list.

The figures in the second column refer only to the plate in which the illustration of the part is shown and are **NOT TO BE USED** in ordering.

Two or more numbers over a cut indicate that the difference between such parts is not visible in an illustration.

Parts marked with an asterisk (\*) are furnished only when repairs are made at the factory.

## LIST OF PARTS COMPLETE

FOR

## MACHINE No. 503w1

For Foot Power Cutting or Snipping Shoe Vamps.

No.	Plate	Name	Each
260501	14820	Base .....	\$5 00
260502	14830	Cutting Bar .....	1 75
731	14829	" " Screw .....	08
260503	14829	" " Washer .....	25
260504	14829	" " Spring .....	20
260505	14829	" " Collar with 200440c ..	40
200440c	14829	" " " " Position Screw ..	04
*260506	-	" Plate with 200338c and 201518E ..	---
200338c	14829	" " Position Screw .....	04
201518E	14829	" " " " Check Nut ....	04
260532	14829	Knife .....	18
260533	14829	" Clamping Washer .....	1 00
260534	14831	" " " (fibre) .....	20
*260535	-	" Holder .....	---
260587	14829	" " Position Bracket .....	35
260586	14829	" " " " Position Pin (2) .....	01
200150B	14829	Knife Holder Position Bracket Screw ..	06
40025	14829	" " " " Pin .....	01

## ACCESSORIES

No.	Plate	Name	Each
36578	14830	Oiler with 36579 .....	8 10
36579	14830	" Spout, 3 in. long .....	06
225498	14830	Screw Driver, 7¼ in. long .....	15
260588	14830	Treadle .....	30
260589	14830	" Bracket .....	15
260590	14830	" " 260589 with 260588, 260591 and two wood screws 1¼ in. No. 12 .....	50
260591	14831	Treadle Hinge Pin .....	05
260593	14830	" Pitman Rod (lower) with 260594 ..	20
260594	14831	" " " " Nut .....	10
228032	14831	" " " " Washer ..	01
227956	14830	" " " (upper) .....	08
204126	14831	" " " Clamp with two 200530c ..	20
200530c	14831	" " " " Set Screw .....	05
260592	14830	Treadle Pitman complete, Nos. 227956, 228032, 260593 and two 204126 .....	70
225554	14831	Wrench (steel) .....	10
		Three wood screws 1½ in. No. 14.	

## NUMERICAL LIST OF PARTS

## NUMERICAL LIST OF PARTS FOR MACHINE No. 503w1

No.	Plate	Name	Each
731A	14829	Cutting Bar Screw .....	\$ 08
36578	14830	Oiler with 36579 .....	10
36579	14830	" Spout, 3 in. long, for 36578 .....	06
40025	14829	Knife Holder Position Pin .....	01
200150b	14829	" " " Bracket Screw ....	06
200338c	14829	Cutting Plate Position Screw, for 260506	04
200410c	14829	" Bar Spring Collar Position Screw, for 260505 .....	04
200530c	14831	Treadle Pitman Rod Clamp Set Screw, for 204126 .....	05
201518c	14829	Cutting Plate Position Screw Check Nut, for 260506 .....	04
204126	14831	Treadle Pitman Rod Clamp with two 200530c, for 260592 .....	20
225498	14830	Screw Driver, 7½ in. long .....	15
225554	14831	Wrench (steel) .....	10
227956	14830	Treadle Pitman Rod (upper), for 260592	08
228032	14831	" " " (lower) Nut Washer, for 260592 .....	01
260501	14830	Base .....	5 00
260502	14830	Cutting Bar .....	4 75
260503	14829	" " Screw Washer .....	25
260504	14829	" " Spring .....	20
260505	14829	" " " Collar with 200440c ..	40
*260506	-----	" Plate with 200338c and 201518c ..	—
260532	14829	Knife .....	18
260533	14829	" Clamping Washer .....	1 00
260534	14831	" " " (fibre) .....	20
*260535	---	" Holder .....	—
260586	14829	Knife Holder Position Bracket Position Pin .....	01
260587	14829	Knife Holder Position Bracket .....	35
260588	14830	Treadle, for 260590 .....	30
260589	14830	" Bracket, for 260590 .....	15
260590	14830	" " 260589 with 260588, 260591 and two wood screws 1½ in., No. 12 ...	50
260591	14831	Treadle Hinge Pin, for 260590 .....	05
260592	14830	Treadle Pitman complete, Nos. 227956, 228032, 260593 and two 204126 .....	70
260593	14830	Treadle Pitman Rod (lower) with 260591, for 260592 .....	20
260594	14831	Treadle Pitman Rod (lower) Nut, for 260593 .....	10

**ILLUSTRATIONS OF PARTS  
FOR  
MACHINE No. 503w1**




PLATE 14830-ONE-FOURTH SIZE




PLATE 14831-FULL SIZE

