# C12

			.₩.	00	######################################	mm	Needle No.	S.P.M. (Max)
C007J-W512-240/FE	2	4	4.0	1:0.3~1:2.9	1.4~3.6	5	UYX128GAS#10	4500
C007J-W512-248/FE	2	4	4.8	1:0.3~1:2.9	1.4~3.6	5	UYX128GAS#10	4500
C007J-W512-356/FE	3	5	5.6	1:0.3~1:2.9	1.4~3.6	5	UYX128GAS#10	4500
C007J-W512-364/FE	3	5	6.4	1:0.3~1:2.9	1.4~3.6	5	UYX128GAS#10	4500
C007JD-W512-240/FE	2	4	4.0	1:0.3~1:2.9	1.4~3.6	5	UYX128GAS#10	4500
C007JD-W512-248/FE	2	4	4.8	1:0.3~1:2.9	1.4~3.6	5	UYX128GAS#10	4500
C007JD-W512-356/FE	3	5	5.6	1:0.3~1:2.9	1.4~3.6	5	UYX128GAS#10	4500
C007JD-W512-364/FE	3	5	6.4	1:0.3~1:2.9	1.4~3.6	5	UYX128GAS#10	4500


#### **DESCRIPTION**



## **ELECTRIC ELASTIC OR LACE ATTACHING**

Elastic feeding evenly length and elasticity controlled by electronic digital control box, for elastic or lace attaching smoothly and properly on women's underwears. Remark:

The maximum width of elastic tape is 2-1/2"



#### **OPTION**

DEVICE		TABLE		
.CL .LF-A .CL/LF-A	Model	Clutch	Servo	C007-T23
	C007J	T32xxHx	T72xx	
	C007JD	-	TA401xx T6400xx	C007-T25

# STANDARD



# FE (J) ELECTRIC TYPE ELASTIC FEEDING

- 1. Elastic feeding evenly length and elasticity controlled by electronic digital control box.
- 2. Maximum feeding width of elastic is 2-1/2".

### Available Model:

C007J-W512, C007JD-W512 C007J-W522, C007JD-W522 F007J-W512, F007JD-W512 F007J-W522, F007JD-W522