


	3	5	5.6	1:0.3~1:2.9	1.4~3.6	5	UYX128GAS#11	4500	
C007J-W522-356/CR/FE	3	5	5.6	1:0.3~1:2.9	1.4~3.6	5	UYX128GAS#11	4500	
C007J-W522-364/CR/FE	3	5	6.4	1:0.3~1:2.9	1.4~3.6	5	UYX128GAS#11	4500	
C007JD-W522-356/CR/FE	3	5	5.6	1:0.3~1:2.9	1.4~3.6	5	UYX128GAS#11	4500	
C007JD-W522-364/CR/FE	3	5	6.4	1:0.3~1:2.9	1.4~3.6	5	UYX128GAS#11	4500	



**DESCRIPTION**

**ELASTIC / LACE ATTACHING WITH RIGHT SIDE FABRIC TRIMMER**

Elastic feeding evenly length and elasticity controlled by electronic digital control box. With right hand side fabric trimmer for elastic or lace attaching smoothly and properly on women's underwears.



**OPTION**

DEVICE	MOTOR			TABLE
.CL	Model	Clutch	Servo	C007-T25
.LF-A	C007J	T32xxHx	T72xx	
.CL/LF-A	C007JD	-	TA401xx T6400xx	

**STANDARD**



**CR**  
**RIGHT HAND SIDE TRIMMER**

Right hand side waste fabric trimming with waste suction device makes fabric edge aligned to seam and keeps the working area clean.

**Available Model:**  
C007J-W522, C007JD-W522

**Self-installation : N**



**FE (J)**  
**ELECTRIC TYPE ELASTIC FEEDING**

1. Elastic feeding evenly length and elasticity controlled by electronic digital control box.
2. Maximum feeding width of elastic is 2-1/2".

**Available Model:**  
C007J-W512, C007JD-W512  
C007J-W522, C007JD-W522  
F007J-W512, F007JD-W512  
F007J-W522, F007JD-W522